


## Interior for 5 ton truck M923A2

---

### Fasteners

- Screw M2x8 DIN7985 – 21 pcs.



## Step 1. Assembling the seat (4 pcs.)


---



Version without stand  
*(used on the 5 ton truck)*





Version with stand  
*(you can put it on a shelf)*













Stand




## Step 2. Assembling interior

---








Cup\_holder\_4pcs






































5 Ton truck cabin  
*(not included)*

Installing interior  
*(instructions for 5 Ton  
truck cabin available on  
[cults3d](https://cults3d.com))*



**Well done!**